MANUAL TO SET UP LOCAL PRINTERS AND CONNECTING TO PORTAL

1. Local-Printer Set up

To install and set up the printer go to **Control Panel** > **Devices and Printers** > **Add a Printer** and go through the process of adding a printer.


Once the printer is added, it is mandatory that the paper format setting on printer is set to the size of the labels that will be printed by the printer. Portal currently supports 2 types of label printing.

- Unit
- Carton

Carton Label size – 105 x 150 mm

Unit Label size – 35 x 40 mm

Go to printer preferences and set Paper Format set. Example shown for unit label:




Apply the printer settings and proceed to repeat the local printer set up for carton printer with values from label size for carton. Once the local printer set up is complete. We can proceed to set up the one time setting on the portal that will generate labels based on the printer settings.


2. Portal Printer Setting:

We need to install <u>QZ Tray</u> so that the webpage and your local printers can talk to each other. Download and install the latest version please. Old versions probably won't work. If you have any issues in installing QZ Tray please contact fusion retail brands support.

Once installed, Go to the <u>portal</u> and go to Setting page. The default values populated are usually correct values for label height and width and label per row, change if required. If the client program QZ Tray is installed and running, the local printers should be populated in the dropdown as values like shown below



If you are unsure about the density setting, you can check the values by print the configuration for the label by going into printer preferences > tools and select Print and Print configuration label and click send.



The density is mentioned on the ususally, if its not mentioned pick the lowest values. Example config label is shown with density highlighted.(203dpi).

```
MAXIMUM LENGTH
EARLY WARNING
USB COMM.
PARALLEL COMM.
 39.0IN 988MM...
MAINT. OFF...
NOT CONNECTED...
BIDIRECTIONAL...
                                                                                                 SERIAL COMM.
  RS232.....
                                                                                                 BAUD
  9600.
  8 BITS.....
                                                                                                 DATA BITS
   NONE.....PARITY
XONZXOFF.....HOST HANDSHAKE
XON/XOFF.
NONE.
NONE.
NORMAL MODE
COMMUNICATIONS
CONTROL PREFIX
CONTROL

                                                                                                 WEB SENSOR
MEDIA SENSOR
    050....
   080.....
                                                                                                  RIBBON SENSOR
    048........
                                                                                                TAKE LABEL
MARK SENSOR
MARK MED SENSOR
TRANS GAIN
TRANS BASE
TRANS LED
     255.........
   027.....
027....
002....
     017......
                                                                                                   RIBBON GAIN
     001.....
                                                                                                  MARK GAIN
MARK LED
     002...............
                                                                                                   MODES ENABLED
     DPCSNFXM.....
     832 8/MM FULL....
                                                                                                  RESOLUTION
                                                                                                  LINK-OS VERSION
FIRMWARE
XML SCHEMA
HARDWARE ID
     RAM
                                                                                                  RAM
ONBOARD FLASH
FORMAT CONVERT
IDLE DISPLAY
RTC DATE
RTC TIME
ZBI
ZBI VERSION
      65536k.....E:
      NONE DDZMMZYYYY 12HR....
      17/01/18......
07:10 AM.....
      DISABLED....
```

Select and set the printer for Unit and Carton. Every time the settings are saved, sample labels will be generated for both Unit and Carton Labels. Please print them and check before starting to print order labels.

If the print is small, try increasing the density values and vice versa and print the labels.